

Charge

Fully charge headphones (~3 hours) until blue LED light illuminates

Pairing

Activate Bluetooth on your device.

Turn the headphones on by holding the Power/Multi-Function Button until you hear "Power On". Upon first use, the headphones will immediately enter "discoverable" mode (indicated by alternating red/blue flashing light) - this means they are ready to pair to a device.

Select "Status Audio BT One" in the Bluetooth menu on your device.

Once paired, the red and blue light will

stop flashing and you'll hear an audio confirmation.

The headphone pairing procedure may vary depending on the settings of your device. If necessary, please contact the manufacturer of the device for further information.

Notes On Pairing

If the headphones are on and no previously paired devices are within range, the headphones will automatically enter “discoverable” mode.

If already paired and you desire to break the connection and connect to another Bluetooth source, simply double-tap the Power/Multi-Function Button. This will

cancel the current connection and enter “discoverable” mode (flashing red/blue light).

If a streaming connection is broken by an accidental double tap of the Power/Multi-Function Button, one additional press of Power/Multi-Function Button will restore the connection to the most recently paired source.


Cabled Connection

The BT One headphones come with a 2.5mm to 3.5mm cable for wired use, so you can enjoy music/audio when the battery is depleted or Bluetooth isn't available.

Play

The BT One headphones allow you to control music playback and incoming phone-calls.

Control functionality may vary depending on device.



Controlling Your Headphones

The BT One headphones utilize simple intuitive commands to control your music, audio, and incoming phone calls.

Please note the difference between volume and track control - a double tap of +/- will change tracks, while holding or single-tapping of +/- changes volume.

For minimal volume changes, we recommend single taps of +/- . To dramatically change volume, press and hold +/- .

Action

Command

Power On

Hold 

Power Off

Hold 

Volume Up

Hold / Tap 

Volume Down

Hold / Tap 

Track Fwd

Double Tap 

Track Rwd

Double Tap 

Play / Pause

Tap 

Pickup / Hangup Call

Tap 

Break Connection +
Re-enter discoverable mode

Double Tap 

FCC STATEMENT :

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.

RF warning statement:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.